

Interchangeable Clutch Shaft Bearings

DIRECTIONS—All Clutch Shaft Bearings listed under one number, such as B11, are interchangeable. The letter T indicates a taper roller bearing and B indicates a ball or roller bearing. The first number after the T is for the cup and the second number is for the cone. Also read directions at top of page 74.